

**CONVERSION TABLE FROM NET PAN EVAPORATION TO TURBOMIST
EFFICIENCY ESTIMATES FOR THE TURBOMIST S30P EVAPORATOR**

This chart is indicated in inches per month. If you have annual pan evaporation in feet, convert to inches and divide the total by 12 months to determine the average pan evaporation rate to use below.

Net Pan evaporation (inches / month) Inches	Percentage of volume pumped aloft	Net Pan evaporation (inches / month) Inches	Percentage of volume pumped aloft
1.5	2%	9.5	45%
1.75	24%	10	46%
2	27%	10.5	47%
2.25	28%	11	48%
2.5	29%	11.5	49%
3	30%	12	50%
3.25	31%	12.5	51%
3.5	32%	13	52%
3.75	33%	13.5	53%
4	34%	14	54%
4.5	35%	14.5	55%
5	36%	15	56%
5.5	37%	15.5	57%
6	38%	16	58%
6.5	39%	16.5	59%
7	40%	17	60%
7.5	41%	17.5	61%
8	42%	18	62%
8.5	43%	18.5	63%
9	44%	19	64%